



Kestrel Court, Harbour Road, Portishead, Bristol, BS20 7AN

Phone: 01275 390603

Web: www.washwareessentials.co.uk

E-mail: enquiries@washwareessentials.co.uk

GreasePaK Refill Cartridge Instructions

GreasePaK Biological Drain Maintenance System

by **MECHLINE**

Box Contents: 5 Litres GreasePaK fluid. For use with Mechline GreasePaK DMi Dispensing Unit only. Mechline GreasePaK MSGD5 fluid uses a complex blend of microorganisms that have been specially formulated to degrade fats, oils and greases in commercial kitchen drains. **IMPORTANT:** Please refer to safety data on reverse.

EMPTY

To remove **EMPTY** fluid box:

1

Wind black GreasePaK connector **ANTI-CLOCKWISE** to disconnect.

2

Carefully lift empty box away from spring and recycle components appropriately.

Storage & safety notes:

- Store product in a cool dry place.
- Wash hands after use.
- Avoid ingestion of liquid.
- Should product contact skin or eyes rinse thoroughly with clean cool water. Should eye irritation continue, seek medical advice.
- In case of ingestion **DO NOT** induce vomiting and seek medical advice.

WARNING:

Failure to replace fluid boxes when needed could put your drains at risk and violate local water authority requirements for on-site grease management of your operations.

